

OrcaCom Feature Codes



Call Transfers:

- #0xxx Attended transfer (allows you to announce the caller before transferring)
- ##xxx Blind transfer (immediately sends the caller to the chosen number)

What are the * codes for changing my OrcaCom features settings via the phone?

- *55 Access Voicemail Portal
- *99 Voice Portal Menus
- *72xxx Call Forward Always Activation
- *73 Call Forward Always Deactivation
- *92xxx Call Forward No Answer Activation
- *93 Call Forward No Answer Deactivation
- *90xxx Call Forward on Busy Activation
- *91 Call Forward on Busy Deactivation
- *561xxx Enable and Set 'Locate Me' Number 1
- *571 Deactivate 'Locate Me' Number 1
- *562xxx Enable and Set 'Locate Me' Number 2
- *572 Deactivate 'Locate Me' Number 2
- *563xxx Enable and Set 'Locate Me' Number 3
- *573 Deactivate 'Locate Me' Number 3
- *78 Do Not Disturb Activation
- *79 Do Not Disturb Deactivation
- *30 Caller ID Blocking Activation
- *31 Caller ID Blocking Deactivation
- *77 Anonymous Call Rejection Activation
- *87 Anonymous Call Rejection Deactivation
- *60xxx Selective Call Rejection (Blacklist) Addition
- *80xxx Selective Call Rejection (Blacklist) Removal
- *65xxx Make a call with Caller ID visible
- *67xxx Make a call with Caller ID blocked
- *32 Anonymous caller screening Activation
- *33 All callers screening Activation
- *34 Call screening Deactivation
- *94xxx Remote Dialtone Service Number Addition
- *95xxx Remote Dialtone Service Number Removal
- *96xxx Remote Call-back Service Number Addition
- *97xxx Remote Call-back Service Number Removal
- *98xxx Remote Access Authorisation Pin Setup
- *98 Removal of Remote Access Authorisation Pin (Trusted ANI only)
- *40 Activate conferencing for my number (turn into conference room)
- *41 Deactivate conferencing for my number
- *42 Access your own conference room
- *61 Call Waiting Activation
- *81 Call Waiting Deactivation
- *69 Call Return (Call back your last caller)
- *66 Last Number Redial
- *51 Who last called me?
- *37xxx Set Authorisation Pin Code
- *37 Remove Authorisation Pin Code (no digits after *37)
- *74x Program Speed Dial 8 (x can be 2-9)
- *52 Toggle to activate/deactivate OrcaCom voicemail system
- *54n Set Call Diversion Timer where 'n' is number of seconds

OrcaCom Feature Codes

Q. I can't be bothered remembering star codes – is there an easier way?

A. Yes - you can use the IVR menu for features. Simply dial *99 and listen to the prompts. Or you can log into OrcaCom live and change your settings online.

